

MZR Phase 90
CUSTOM SCRIPT PHASE

LIVE TO PLAY LIVE®



JIMDUNLOP.COM

92503004780revC

**Operation
Manual**

CSP101SL SCRIPT PHASE 90

DESCRIPTION

- Built to original 1974 circuit design
- Features AC power jack and on/off status LED
- True bypass

POWER

The MXR Script Phase 90 is powered by one 9-volt battery (remove bottom plate to install), a 9-volt AC adapter such as the Dunlop ECB003/ECB003E, or a DC Brick™ power supply.

CONTROLS

- SPEED knob controls rate of phase effect
- FOOTSWITCH toggles effect on/bypass (indicated by red LED)

DIRECTIONS

- Run a cable from your guitar to the Script Phase 90's Input jack and run another cable from the Script Phase 90's Output jack to your amplifier.
- Start with the SPEED knob at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate the SPEED knob clockwise for a faster phase effect and counterclockwise for a slower phase effect.

SAMPLE SETTINGS

CLASSIC 80's ROCK

9:00



SPEED

PSEUDO LESLIE

12:00



SPEED

SPECIFICATIONS

Input Impedance	470 kΩ
Output Impedance	10 kΩ
Max Input Level	-5 dBV
Noise Floor*	> 95 dB
Current Draw	8.2 mA
Bypass	True Hardwire
Power Supply	9 volts DC

*A-weighted, all controls at mid position

