

CLIP ON TUNER

Super Large Character Display

The DT-C4 tuner is a high-precision tuning tool with a super large character display, designed to enhance visibility and ease of use. It is suitable for instruments such as guitar and bass, supports half-step tuning mode, and is simple to operate, making it convenient for quick tuning during performances.

NOTICE FOR SAFETY USE


1. OVERALL

- Never use alcohol, petrol, or other strong chemical cleaners to wipe the exterior or the LCD.
- Do not crush or strike the exterior, as this may cause malfunctions or damage to the unit.

2. BATTERY USE

- Ensure correct polarity when inserting a new battery.
- Remove the battery if the unit will not be used for an extended period.
- If the unit isn't functioning properly, remove and reinsert the battery after 10 seconds.
- Replace the battery with a new one if the LCD display becomes weak or unclear.
- Dispose of the old battery properly.

PRODUCT




QUICK START

1. POWER ON AND OFF

Briefly press the power button to turn on the tuner, or press and hold for 2 seconds to turn it off.


2. TUNING DISPLAY



Too flat



In tune



Too sharp

3. AUTOMATIC TURN OFF

Automatic shutdown after 5 minutes to conserve battery life.

SPECIFICATIONS

Color VA-LCD screen with super large character display and easy-to-read tuning needle

Tuning Mode	chromatic
Tuning Range	B0-B7
A4 Calibration	440 HZ
Tuning Accuracy	+ / -1 cent
Power	3V CR2032 battery
Accessories	Manual, CR2032 battery
Dimensions	W : 36 mm x H : 36mm x D : 23mm
Weight	29g

BATTERY REPLACEMENT

Please pay attention to the positive and negative of the battery, when opening the battery cover and put in a CR2032 battery. If the tuner shows some malfunctions such as screen shutdown, do not press the Power button. Simply take the battery out and put it in again. This should solve the problem.



DUNLOP MANUFACTURING, INC.
P.O. BOX 846 BENICIA, CA 94510 | JIMDUNLOP.COM