

LIVE TO PLAY LIVE®





92503016096 revB

M101 PHASE 90

DESCRIPTION

- Add's shimmery velocity to lead licks and a thick swoosh to chords
- Works well with bass, keyboards and even vocals
- True bypass

CONTROLS

- SPEED knob controls overall effect rate
- 2 FOOTSWITCH toggles effect on/ bypass (red LED indicates on)

POWER

1

2

UTPU

The MXR Phase 90 is powered by one 9-volt battery (remove bottom plate to install), a 9-volt AC Adapter such as the Dunlop ECB003/ECB003EU or a DC Brick[™] power supply.

SPEED

IMXF

 \cap

phase 90

DIRECTIONS

- Run a cable from your guitar to the Phase 90's INPUT jack and run another cable from the Phase 90's OUTPUT jack to your amplifier.
- Start with the SPEED control at 12 o'clock.
- Turn the effect on by depressing the footswitch.
- Rotate the SPEED knob clockwise for a faster phase effect or counterclockwise for a slower phase effect.

SPECIFICATIONS

Input Impedance	1 ΜΩ
Output Impedance	10 kΩ
Nominal Intput Level	-20 dBV
Nominal Output Leve	-20 dBV
Noise Floor*	-96 dBV
Bypass	True Hardwire
Current Draw	5 mA
Power Supply	9 volts DC
*A-weighted	





DUNLOP MANUFACTURING, INC. P.O. BOX 846 BENICIA, CA 94510 U.S.A. TEL: 1-707-745-2722 FAX: 1-707-745-2658