

WM81

WAY HUGE[®]
SMALLS[™]
STONE BURNER[™]
SUB ATOMIC
FUZZ

**STONE BURNER! SOMEONE
SCREAMED.**

Playing with the Way Huge Stone Burner Sub Atomic Fuzz is like playing with molten lava—it's all fun and games until somebody gets scorched. But that's the whole point with this dastardly little box. Mr. Huge designed the Stone Burner Sub Atomic Fuzz as your all-purpose companion—have some fun, and explore the outer reaches of your sanity. Fire up the Way Huge Smalls Stone Burner Sub Atomic Fuzz, and get weird. But remember to protect your eyes...

External Controls



- 1** FOOTSWITCH toggles effect on/bypass (blue LED indicates on)
- 2** TONE knob adjusts overall tone of effect
- 3** VOLUME knob adjusts level of fuzz effect
- 4** SUB 1/SUB 2 switch selects between Sub 1 (one octave down) or Sub 2 (two octaves down)
- 5** SUB knob adjusts level of sub-octave signal
- 6** FUZZ knob sets intensity of fuzz effect

POWER

The Way Huge® Smalls™ Stone Burner™ Sub Atomic Fuzz is powered by a single 9-volt battery (remove bottom plate to install), a 9-volt AC adapter such as the Dunlop ECB003, or an MXR® Brick™ Series power supply. The power input is a 5.5mm x 2.1mm jack with the positive voltage on the outer sleeve. Using an external power supply will disconnect the battery. Disconnect the input jack to preserve battery life when not in use.

Specifications

Input Impedance	> 800 k Ω
Output Impedance	< 2 k Ω
Noise Floor*	< -97 dBV
Current Draw	8 mA
Power Requirements	9 volts DC

*A-weighted, all controls at mid position.