

cry baby
NOCENTELLI®



BASIC OPERATION

POWER

The Cry Baby® Leo Nocentelli Wah is powered by one 9-volt battery (accessible via bottom of pedal), the Dunlop ECB003 9-volt adapter, or a Brick™ Series power supply.

OPERATION

1. Run an instrument cable from your guitar to the LN95's INSTRUMENT jack and another instrument cable from the LN95's AMPLIFIER jack into your amplifier's input.
2. Push the toe of the pedal down until you feel a "click" to turn the pedal on/off.
3. Rock your foot back and forth on the pedal to hear the vocal, expressive tones that the Cry Baby Wah is famous for.

SPECIFICATIONS

IMPEDANCE

Input Impedance	800 k Ω
Output Impedance	10 k Ω

CENTER FREQUENCY

Heel Down	290 Hz to 310 Hz
Toe Down	1.4 kHz to 1.5 kHz

Max Input Level	8 dBV
Max Gain	16.5 dB
Bypass	Hardwire
Current Draw	900 μ A
Power Supply	9 volts DC